



Stressless Panorama



Stressless® Panorama - Measurements (inches)

Item no.	Model	Width	Height	Depth	Seat Height	Seat Depth
1402020	Panorama 2 Seat	62.6	32.7	33.5	17.3	21.3
1402030	Panorama 3 Seat	85.4	32.7	33.5	17.3	21.3

Leg Options: Wood Bow - Steel Bow

Unlike other Stressless sofas, Stressless Panorama has a fixed angle between seat and back. When seated, you will feel the BalanceAdapt-system effortlessly adjusts the seat and back to your desired sitting angle. The seat and back respond to your movements with a subtle and comfortable rocking movement, offering personal comfort and perfect balance to each seat.









