Remote Control User Guide

Novo XT2

CURRENT PROGRAM – Details of current program, including program name, intensity levels, and current focus area.

TIME REMAINING – Shows the total amount of remaining time in your massage session.

MENU – Displays the main menu.

AUTO – Displays the Auto Programs menu. When an auto program is running, press to toggle among the other auto programs. The active program displays at the top of the status screen.

CLOUD – Press to adjust the Cloud Touch intensity. The selected intensity displays in the upper left-hand corner of the screen.

BACK – Press and hold to recline or incline the backrest.

ZeroG® – Press and hold to automatically position the chair in ZeroG mode, raising your feet above your heart for maximum spine relief.

LEGS EXTEND – Press and hold to extend the footrest.

STOP/POWER/RESTORE – Press this button:

- To power on the remote.
- If the power is on, use this to select STOP and stop your massage immediately.
- To select POWER OFF, then select RESTORE to return the chair to the upright position before exiting.

POSITION – Use to move the massage rollers to the desired position when enjoying a Zone or Spot massage.

HEAT – Press to toggle the heat on and off. When the heat is on, the heat icon on the screen displays red.

LEGS – Press and hold to raise or lower the footrest.

LEGS RETRACT – Press and hold to retract the footrest.

For more detailed operation instructions, please see the Use and Care Manual.

human touch
be your best. feel your best.™