


get ready




UNPACK THE BOXES



INSTALLING THE FOOTREST FRAME


1. Remove the footrest frame screws.

Using the Phillips-head screwdriver (provided), remove the two screws from the footrest frame. Retain them for use in step 3.




2. Slide the footrest frame onto the chair frame.

Slide the two ends of the footrest frame into the holes in the front of the chair frame.




3. Replace the footrest frame screws.

Using a Phillips-head screwdriver and the two provided screws, secure each side of the footrest frame to the chair frame.




4. Attach the canvas to the footrest frame.

Using both hands, gently pull the seat canvas forward just to the top of the footrest frame, then secure the two flaps located underneath the canvas to the footrest frame.



5. Finish securing the canvas to the frame.


Using both hands, continue to pull the seat canvas all the way forward to cover the footrest frame, then secure the two front and two side flaps, using the hook and loop fasteners.



ATTACH THE BODY PAD

1. Slide the body pad onto the chair frame.

Slide the body pad onto the lower part of the chair frame, making sure that the frame slides into the fabric pocket located on the bottom side of the pad.



2. Secure the body pad.

Smooth the body pad into place, from the footrest toward the backrest. The pad is automatically secured using the hook and loop fasteners.



get ready



ATTACH THE HEADREST FRAME

1. Raise the chair to an upright position.

For your convenience, and to better position the chair for the remaining assembly, use the recline lever to adjust the chair to an upright position.


2. Remove the headrest frame screws.

Using the Phillips-head screwdriver (provided), remove the two screws from the headrest frame. Retain them for use in step 4.



3. Insert the headrest frame into the backrest frame.

With the arc of the headrest frame pointing toward the back of the chair, slide the two ends of the headrest frame into the open tube ends at the top of the backrest frame.



4. Replace the headrest frame screws.


Using a Phillips-head screwdriver, replace the two headrest frame screws, securing the headrest frame to the backrest frame.



ATTACH THE HEAD PAD


1. Slide the head sock over the headrest frame.

Slide the head sock over the headrest frame, as far as it will go. The padded side of the head sock should face the back of the chair.



2. Slide the head pad over the head frame.

Slide the head pad over the head frame, ensuring that the frame slides into the fabric pocket located on the bottom side of the pad. Pull the head pad down as far as it will go.



3. Tuck in the body pad flap.

From the front of the chair, tuck the flap on the top of the body pad up into the head pad and smooth it flat. The flap is automatically secured to the pad, using the hook and loop fasteners.




4. Attach the head pillow.

Attach the head pillow straps to the head pad straps using the hook and loop fasteners. Adjust the head pillow height for maximum comfort.



ATTACH THE ARM CAPS


Remove the three screws taped to the underside of the right-hand arm cap, then place the right-hand arm cap on top of the armrest. From the underside of the armrest, secure the arm cap using the three screws. Repeat these steps to attach the left-hand arm cap.



Adjust the recline angle

To recline, gently pull up on the recline lever, lean back on the backrest to adjust it to the desired angle, then release the lever. To incline to a more upright position, gently pull up on the recline lever, then pull up on the armrests with your hands while applying slight downward pressure with your elbows, until the backrest inclines to the desired position. Release the recline lever.

NOTE: Lean back against the backrest before reclining the chair.



Adjust the headrest

While seated, reach up with both hands and grasp both sides of the headrest. You will feel the rigid frame beneath the soft head pad. Grasping the rigid frame, tilt the headrest forward or backward for maximum comfort. The headrest remains in this position until you adjust it again.



ⓘ When adjusting the footrest up and down, you may notice a slight bumping sensation. This is caused by the footrest locking mechanism, and is perfectly normal.